



One of the most difficult things for a bowler to do is visualize the ball path from the foul line to the breakpoint. From entry level bowlers to the most advanced, the Torch allows bowlers to see the initial path of the bowling ball like no other product before.

The Torch is a simple light targeting tool used to help with accuracy and alignment. Using LED lights, it reflects a path of light on the lane to help you select the correct launch angle and hit your target time after time. As you move left and right, the light will change its position showing you exactly where you should throw the ball.

important fundamental skill.



TORCH BENEFITS
Helps define a bowlers starting point
Helps bowlers to see the laydown point
Helps keep the swing path in-line with the target path
Helps keep the head stable throughout the




 Shows how the target changes if a bowler drifts left or right


The Torch was designed to explain the aiming process in a way that can be easily understood by everyone. From children, to beginning bowlers, to special needs bowlers, the Torch is an easy and fun way to quickly improve this

See the Torch in action at: www.kegel.net/torch

Torch Complete SystemPart Number: 157–8800









TORCH

LANE TARGETING LIGHT

Torch Tilt Bar System

Add the ability to tilt your Torch. Ideal for 2-handed and left-eye dominant players.

Part Number: 157-8809

Torch Light Trigger System

Trigger switch flashes light on and off when you hit your target.

Part Number: 157-8816

Torch Tilt Bar and Light Trigger System with Color Change

the light bar on your original Torch to a colored version

with the trigger and tilt bar.

Part Number: 157-8817

Torch 2-Piece Adjustable Height System - White Light

2-piece top assembly for height adjustments; white light.

Part Number: 157-8808

Optional Battery

Part Number: 157-8801







- All Torch Features
- Multiple light color options
- Torch Tilt Bar System
- Torch Light Trigger System
- Torch 2-Piece Adjustable Height System

Torch-X Complete System Part Number: 157–8810

Optional Battery

Part Number: 157-8801

